

For When Speed and Results Matter



Save Time & Money with 3M Hand-Masker Products

Help Save Time and Money with These Tools

Tools



M3000

3M[™] Hand-Masker[™] M3000 Dispenser

- Applies masking tape to masking film, plastic or paper in one continuous application
- Preps 4X faster than the paper/poly method
- Handles all sizes of film or paper up to 12", including: AMF, MPL, CP, MPG



M3000-PAK-SC

3M[™] Hand-Masker[™] M3000 Kit

- Assembled Kit includes: Dispenser, Straight Cut Blade, AMF Film, 2090 Original Tape
- Preps 4X faster than the paper/poly method



FB12-SC

3M[™] Hand-Masker[™] Straight Cut Film Blade, 12"

- Delivers a straight cut time after time
- Save time and materials when masking
- Use with 3M[™] Hand-Masker[™] M3000 dispenser to cut film, paper or plastic



FB12

3M[™] Hand-Masker[™] Film Blade, 12"

- Saves time with faster, easier prep*
- Use with 3M[™] Hand-Masker[™] M3000 dispenser to cut film, paper or plastic



PB9, PB12

3M[™] Hand-Masker[™] Paper Blade

- Saves time with faster, easier prep*
- Use with 3M[™] Hand-Masker[™] M3000 dispenser to cut paper or plastic

*Compared to the paper/poly method

Paper



MP

3M™ Hand-Masker™ Premium Quality Masking Paper

- Specially formulated to minimize bleed-through with most solvent and oil-based materials
- Protects windows, trim, railings & drywall from paint drips and overspray



MPG

3M[™] Hand-Masker[™] General Purpose Masking Paper

- Ideal for water-based coatings
- Protects windows, trim, railings & drywall from paint drips and overspray

Film & Plastic



AMF 3M™ Hand-Masker™ Advanced Masking Film

- Maximized paint flake resistance for reduced clean-up time
- Optimized for multiple coat paint applications
- Film layers have a hassle-free fold to prevent film from getting caught in tape
- Static cling to cover & protect



MPL

3M[™] Hand-Masker[™] Masking Plastic, 12"

- Ideal replacement for masking paper
- 2x more per roll than 3M[™] Hand-Masker[™] Masking Paper
- Conformable, easy to wrap around objects
- No matter the paint spill, there's never bleed through
- Translucent to allow light through
- Paint-flake resistant



MFB

3M[™] Hand-Masker[™] Painter's Plastic Plus

- Bulk poly in a box for large area paint protection
- Easy to find & tape lead edge
- Flake, lacquer & solvent resistant
- Static cling to cover & protect



CP

3M[™] Hand-Masker[™] Contractor's Plastic

- Ideal for single coat paint application
- Film layers have a hassle-free fold to prevent film from getting caught in tape

Masking Films Selector Guide

			Marie Carlo	
Benefits	AMF	MPL	MFB	СР
Flake Resistance	Exceptional	Great	Great	Good
Static Cling	Exceptional	Great	Excellent	Good
Prevents Bleed Through	Х	Х	Х	х
Allows Light Through	Х	Х	Х	Х
Unfolds for Large Area Coverage	Х		х	Х
Use with 3M [™] Hand- Masker [™] M3000	Х	Х		Х
Sizes	2', 4', 6', 8.25' (24", 48", 72", 99")	1' (12")	9', 12'	4', 6', 9'
Ideal Application	Multiple coat paint splatter, drip, mist or spray protection	Wrapping objects and masking windows for paint protection	Large area dust & overspray protection	Single coat paint protection



3M tapes are designed to work with the 3M[™] Hand-Masker[™] M3000 Dispenser and film due to their smooth unwind and reliable adhesion level.



2090 ScotchBlue[™] Original Multi-Use Painter's Tape



2097

Scotch® Exterior Surface Painter's Tape



2020

Scotch® Contractor Grade Masking Tape



2020+

Scotch® Heavy Duty Masking Tape



2093

ScotchBlue[™] Sharp Lines Painter's Tape

Product Ordering Information

0.34 0.61 0.47 0.63 0.37 0.29 0.47
0.61 0.47 0.63 0.37 0.29 0.47
0.61 0.47 0.63 0.37 0.29 0.47
0.47 0.63 0.37 0.29 0.47
0.63 0.37 0.29 0.47
0.37
0.29
0.29
0.47
0.47
0,61
0.61
1
0.453
0.682
1.1
2.3
0.12
0.12
0.1
0.22
0.46
0.68
0.84
1.27
0.46
0.66
0.86
- 1
1.4 1.5 2.6 1.1 5.6 2.7 2.4 0.9

Tips and Techniques

Sliding Glass Door



STEP 1: Pre-tape one side of the door.



STEP 2: Use the 3M[™]
Hand-Masker[™] M3000
Dispenser to apply film to the opposite side of the door.



STEP 3: Unfold the film and adhere to the pre-taped side of the door. Tape the top and bottom. NOTE: Cut a small slit for ventilation.

Standard Windows



STEP 1: Pre-tape the bottom of the window.



STEP 2: Use the 3M[™]
Hand-Masker[™] M3000
Dispenser to apply film to the top of the window trim.



STEP 3: Unfold the film and adhere to the pre-taped bottom of the window. Tape the sides.

Arched Windows



STEP 1 (not pictured): Pre-tape the sides and bottom of the arched window.



STEP 2: Use the 3M[™] Hand-Masker[™] M3000 Dispenser to apply film to the top of the window.



STEP 3: Unfold the film down the window and adhere to the pre-taped sides and bottom of the window.

Bathtub Inserts



STEP 1: Pre-tape one side of the bathtub insert.



STEP 2: Use the 3M[™] Hand-Masker[™] M3000 Dispenser to apply film to the opposite side of the insert.



STEP 3: Unfold the film and adhere to the pre-taped side of the insert.

