



Time  
Day

\$\$\$ Cost  
Medium

Difficulty  
Intermediate

## Color Remix – Chevron

Turn a plain piece of furniture into a statement piece! Share your color remix with [#SWColorLove](https://www.instagram.com/SWColorLove).

### Supplies For This Project:

**Dresser with Removable Drawers**

**New Knobs (optional)**

**Sherwin-Williams Emerald Interior Acrylic Latex**

**Paint Water + Detergent**

**Tack Cloth**

**Medium Grit 3M™ Sanding Sponge**

**Fine Grit 3M™ Sanding Sponge**

**Purdy Paint Roller Cover for Smooth Surfaces**

**Paint Roller Frame**


**Purdy Paint Brush (2")**

**Exacto-knife**

**ScotchBlue Painter's Tape**

**Premium Wall & Wood Primer**

### Colors Used:



SW 7757  
**High Reflective White**



SW 9175  
**Deep Forest Brown**



SW 6890  
**Osage Orange**

## Instructions:

1. First, select your dresser. We recommend one with drawers that fully remove, and a dresser body that frames each drawer to maximize color contrast.
2. Remove the knobs and clean the dresser with warm water and detergent. Once it's dry, sand the dresser and clean off dust with tack cloth.
3. Prime the body of the dresser and all four drawers with Premium Wall & Wood Primer. Let dry 3-4 hours.
4. Once dry, paint the body of the dresser and the four drawers with your base color. We chose Osage Orange SW 6890 for a bold pop of color. Let the dresser frame and the drawers dry overnight.
5. Measure and mark your design with a pencil. Use ScotchBlue Painter's Tape to create an outline and ensure clean lines. We went with a simple two-tone, chevron-inspired design.
6. Using an exacto-knife, cut the tape along the edges of the drawers so that they can be removed. Remove the drawers from the dresser.
  - **Tip:** You always want to paint on the drawers separately from the dresser in order to avoid painting the drawers shut. However, when you put the drawers back into the frame, the pattern should line up perfectly.
7. Paint the accent colors of your design using an angled Purdy brush to keep your lines clean. We chose Deep Forest Brown SW 9175 and High Reflective White SW 7757.
  - For best results, remove the tape while the second coat is still tacky. If you decide to remove the tape after the paint has dried, you may want to use a craft knife and a straightedge to score the line before pulling the tape.
8. Paint the knobs with one of your selected accent colors. Let them dry completely.
9. Carefully replace the drawers into the dresser frame and screw the painted knobs back into the dresser to finish the look.

## The BEFORE & AFTER...

