



 Time
Afternoon

 Cost
Low

 Difficulty
Easy

Color Remix – Natural Wood with Trim and Handles

Turn a plain piece of furniture into a statement piece! Share your color remix with [#SWColorLove](https://www.instagram.com/SWColorLove).

Supplies For This Project:

Dresser with Removable Drawers

New Knobs (optional)

Sherwin-Williams Emerald Interior Acrylic Latex

Paint Water + Detergent

Tack Cloth

Medium Grit 3M™ Sanding Sponge

Fine Grit 3M™ Sanding Sponge


Purdy Paint Roller Cover for Smooth Surfaces

Paint Roller Frame

Purdy Paint Brush (2")

Premium Wall & Wood Primer

Colors Used:

 SW 9020
Rayo de Sol

 SW 6737
Kiwi

Instructions:

1. First, select your dresser. We recommend one with drawers that fully remove, and a dresser body that frames each drawer to maximize color contrast.
2. Remove the knobs and clean the dresser with warm water and detergent. Once it's dry, sand the dresser and clean off dust with tack cloth.
3. Begin by removing all the drawers from your dresser. We want to create a vintage look with this design, so we are going to preserve the look of the natural wood.
4. We love the look of a bold yellow, so we chose to use Emerald® Interior Acrylic Latex Paint in Rayo de Sol SW 9020. It's both paint and primer, so just one coat is enough. Let dry for several hours.
5. Before painting the knob and dresser trim, prime using Premium Wall and Wood Primer. Let dry, then Using another color of your choice (we are loving this soft green: Kiwi SW 6737), paint your drawer knobs and set aside to dry.
6. Once everything has dried completely, carefully replace the drawers into the dresser frame and screw the knobs back on the drawers.
7. Enjoy your refreshed dresser that now has a unique pop of color!

The BEFORE & AFTER...

