



Time

Afternoon



Cost

Medium



Difficulty

Intermediate

## Color Remix – Pointed Arrows

Turn a plain piece of furniture into a statement piece! Share your color remix with [#SWColorLove](https://www.instagram.com/SWColorLove).

### Supplies For This Project:

**Dresser with Removable Drawers**

**New Knobs (optional)**

**Sherwin-Williams Emerald Interior Acrylic Latex**

**Paint Water + Detergent**

**Tack Cloth**

**Medium Grit 3M™ Sanding Sponge**

**Fine Grit 3M™ Sanding Sponge**

**Purdy Paint Roller Cover for Smooth Surfaces**


**Paint Roller Frame**

**Purdy Paint Brush (2")**

**ScotchBlue Painter's Tape**

**Premium Wall & Wood Primer**

### Colors Used:



SW 7757

High Reflective White



SW 6610

Koral Kicks



SW 6612

Ravishing Coral



SW 6758

Aqueduct



SW 6763

Retiring Blue

## Instructions:

1. First, select your dresser. We recommend one with drawers that fully remove, and a dresser body that frames each drawer to maximize color contrast.
2. Remove the knobs and clean the dresser with warm water and detergent. Once it's dry, sand the dresser and clean off dust with tack cloth.
3. Remove the drawers from the dresser frame. Begin by priming both the entire dresser and all of the drawers using Premium Wall & Wood Primer. Let dry for 3-4 hours.
4. Using a soft bristle brush, begin painting the dresser frame and legs of the dresser in High Reflective White SW 7757.
5. Select two contrasting colors that would contrast well with each other. We wanted to add a little more dimension to the color dynamic by selecting a lighter and darker shade of the two color families. We chose Emerald® Interior Acrylic Latex Paint in Coral Kicks SW 6610, Ravishing Coral 6612, Aqueduct SW 6758, and Retiring Blue SW 6763.
6. Take each one of the drawers that you removed and tape off the sides to create two triangle shapes at each corner. Use your finger to press down on the tape to ensure that there is no spillage.
7. Using a sponge or a soft bristle brush, begin painting each one of the drawers. Use a paintbrush to carefully paint near the edges of the tape. Let dry for several hours.
8. Carefully replace the drawers into the dresser frame, mixing and matching them until you've achieved your desired look.
9. Replace the knobs to finish the design. Enjoy your refreshed dresser!

## The BEFORE & AFTER...

