



 Time
Afternoon

 Cost
Low

 Difficulty
Easy

Color Remix – Wood/Half

Turn a plain piece of furniture into a statement piece! Share your color remix with [#SWColorLove](https://www.instagram.com/SWColorLove).

Supplies For This Project:

Dresser with Removable Drawers

New Knobs (optional)

Sherwin-Williams Emerald Interior Acrylic Latex

Paint Water + Detergent

Tack Cloth

Medium Grit 3M™ Sanding Sponge

Fine Grit 3M™ Sanding Sponge

Purdy Paint Roller Cover for Smooth Surfaces

Paint Roller Frame

Purdy Paint Brush (2")

ScotchBlue Painter's Tape

Premium Wall & Wood Primer

Colors Used:



SW 6981

Passionate Purple

Instructions:

1. First, select your dresser. We recommend one with drawers that fully remove, and a dresser body that frames each drawer to maximize color contrast.
2. Remove the knobs and clean the dresser with warm water and detergent. Once it's dry, sand the dresser and clean off dust with tack cloth.
3. Remove the bottom two drawers. Use painter's tape to tape off the outside border of where you will be painting, making sure to align the tape just below the top drawers.
 - **Tip:** For getting straight lines: Let the tape guide you. Don't pull on it. Try and force straight lines. Keep it a bit loose and just smooth it down lightly with your hand as you go.
4. First, we will be priming the body of the dresser. Use Premium Wall & Wood Primer. Let dry for 3-4 hours.
5. Once dry, begin painting the body of the dresser. Use a paintbrush to carefully paint the edges closest to the tape. We chose Emerald® Interior Acrylic Latex Paint in Passionate Purple SW 6981. Take extra care in painting around the legs of the drawer. We recommend a 4" paintbrush to get into all of the details.
6. Afterwards, paint the two dresser drawers you removed using a sponge or soft bristle brush with the same color.
7. Lastly, paint two of the knobs that you unscrewed in the same color using a 4" paintbrush.
8. Once everything is completely dry, carefully replace the drawers into the bottom half of dresser frame.
9. Screw the painted knobs back on the top drawers and the unpainted knobs on the bottom drawers to finish the look.

The BEFORE & AFTER...

