



 Time
Afternoon

 Cost
Low

 Difficulty
Easy

Color Remix – Wood Trim

Turn a plain piece of furniture into a statement piece! Share your color remix with [#SWColorLove](https://www.instagram.com/SWColorLove).

Supplies For This Project:

Dresser with Removable Drawers

New Knobs (optional)

Sherwin-Williams Emerald Interior Acrylic Latex

Paint Water + Detergent

Tack Cloth

Medium Grit 3M™ Sanding Sponge

Fine Grit 3M™ Sanding Sponge


Purdy Paint Roller Cover for Smooth Surfaces

Paint Roller Frame

Purdy Paint Brush (2")

Premium Wall & Wood Primer

Colors Used:

 SW 6935
**Straightforward
Green**

Instructions:

1. First, select your dresser. We recommend one with drawers that fully remove, and a dresser body that frames each drawer to maximize color contrast.
2. Remove the knobs and clean the dresser with warm water and detergent. Once it's dry, sand the dresser and clean off dust with tack cloth.
3. Remove drawers and prime each each dresser drawer using a soft bristle brush and let dry for 3-4 hours. Once dry, apply paint with a sponge or soft bristle brush. We used Straightforward Green SW 6935 for a bold pop of color. Slowly brush from the center of the face out to the edge.
4. Once it's all completely dry, carefully replace the drawers into the dresser frame, and screw the knobs back on to finish the look. Enjoy your refreshed, colorful dresser that still has a vintage look!

The BEFORE & AFTER...



WARNING! Removal of old paint by sanding, scraping, or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.